


TN21A



TN31A




TN21K




TN31K



TN21T



TN31T



## ILLUMINATED PUSH BUTTON (DIRECT POWER) CONTACT BLOCKS

Type	TN2-11A	TN2-11B	TN2-11C	TN2-12A	TN2-12B	TN2-12C
Contact	1a	1b	1ab	2a	2b	2a2b
Contact Arrangement						

Type	TN2-13A	TN2-13B	TN2-13C	TN2-14A	TN2-14B	TN2-14C
Contact	3a	3b	3ab	4a	4b	4a4b
Contact Arrangement						